

# BT-M6Z02-RF

## 230V/24V



### **USER GUIDE**

*MASTER 6 ZONES RF*

**GB**

2-10

## 1 USER GUIDE

The Connecting box BT-M6Z02-RF is especially designed to control your Under Floor Heating and Cooling system.

It can handle Normally Closed or Normally Opened actuators.

Connecting box has by conception 6 outputs actuators and this number can be extended to 10 or 12 with an extension.

BT-M6Z02-RF works with thermostats linked in RF; it can have up to 12 thermostats linked to it and handle 12 independent regulations in parallel.

It works with all thermostats of BT02 RF and BT03 RF range.

## 2 TECHNICAL CHARACTERISTICS

	BT-M6Z02-RF 230V	
<b>Operating Temperature</b>	0°C to 50°C	
<b>Regulation characteristics</b>	Proportional Integral regulation or Hysteresis regulation. Regulation is defined by thermostat linked to channel (see thermostat leaflet)	
<b>Supply Voltage</b>	230VAC +- 10% 50Hz	
<b>Outputs: Pump or accessories Actuators</b>	Relay => 5A / 250VAC (Free contact) Relay => 5A / 230 VAC ( L, N) For easy installation we recommend a maximum of 4 actuators by zones.	
<b>Radio Frequency</b>	868, 3 MHz, <10mW. Range of approximately 180 meters in open space. Range of approximately 50 meters in residential environment.	
<b>CE Directives</b> Your product has been designed in conformity with the European Directives.	R&TTE 2014/53/EU LVD 2014/35/EU EMC 2014/30/EU RoHS 2011/65/EU Directive on General Products Safety 2001/95/EC	
<b>Protection</b>	IP 30	
<b>Compatibility</b>	With BT S4Z02 RF: 10 Zones => 1 Master 6 + 1 Slave 4 zones With BT S6Z02 RF: 12 Zones => 1 Master 6 + 1 Slave 6 zones BT-HCM02 RF BT-WR02-RF, BT-WR02 FC RF BT-PR02-RF BT-FR02-RF BT-CT02-RF Repeater RF BT-A02 RF BT-D02 RF, BT-D02 RH RF BT-DP02 RF, BT-DP02 RH RF BT-D03 RF	

### 3 User interface



#### 3.A. LED color meanings

On BT-M6Z02-RF there are one bicolor Led per zone (1) to (6) and 2 additional status Leds.

In normal working mode:

- (1) To (6):
  - o **Red fix:** Heating or Cooling demand indicator (Water circulation on this zone)
  - o **Green flash:** RF signal received from the thermostat assigned to this zone
  - o **Red blinking:** RF alarm, the communication between thermostat and the BT-M6Z02-RF has been lost (in this case check batteries on this thermostat)
  - o **Red blinking on all zones:** check the RF antenna connection
- (7): Pump indicator
  - o **Green** when pump output is active
- (8): Heat and Cool indicator
  - o **Green** when cooling
  - o **Red** when Heating
  - o **Red or Green** blinking: RF alarm between the BT-M6Z02 RF and any device other than a thermostat

In RF linking mode Leds indicators (1) to (6) have a different meaning, Refer to 6.

#### 3.B. Buttons

On BT-M6Z02-RF, there are 3 buttons "<", "OK" and ">".

They are used to:


- link elements to BT-M6Z02-RF: refer to section 7
- do a factory reset (reset all configuration and all RF links) : refer to section 7

#### 3.C. DIP swith configuration

When you unscrew the front face of BT-M6Z02-RF, you have access to 4 switches used for advanced configuration:



**By default position is OFF for the 4 switches**



##### **Switch 1: Local / global Pump configuration (pump output AND remote pump device)**

ON (global): BT-M6Z02-RF activates its pump if there is a heat or cool demand in the system

OFF (local): BT-M6Z02-RF activates its pump only if there is a demand on the BT-M6Z02-RF

##### **Switch 2: NO / NC configuration**

ON (NO): Outputs (actuators) are Normally Open

OFF (NC): Outputs (actuators) are Normally Closed

##### **Switch 3: Pump Exercise configuration**


ON: Once a week, pump output is activated.

OFF: No action on pump output


##### **Switch 4: No action**

## 4 WIRING ASSEMBLY DIAGRAM

4.1 WIRING ASSEMBLY DIAGRAM 230V



## 4.2 WIRING ASSEMBLY DIAGRAM 24V



## 5 HOW TO INSTALL CORRECTLY YOUR RF SYSTEM




**Please respect the mounting to optimize sensibility and avoid any dysfunctionment**

Antenna must placed:

- outside the metallic box
- in vertical position
- and at least at 50cm of metallic parts

If you have several antenna (several BT-M6Z02-RF / BT-HCM02-RF in the same place), they must be placed at minimum 80cm of each other.



## 6 SYSTEM POSSIBILITIES:

Please refer to System configuration manual ([www.wattselectronics.com](http://www.wattselectronics.com)), for more information on the different possibilities.


We distinguish 2 types of installation, if you have a BT-CT02-RF in your installation jump to 6.B

### 6.A. Installation without Touchscreen BT-CT02-RF

In this installation, we have 2 subcases:

- 1- Installation "Standalone": Typical installations:
  - a. Only one BT-M6Z02-RF
  - b. Several BT-M6Z02-RF with local pump management
- 2- Installation "Centralized management": In this case, there are several BT-M6Z02-RF that needs to communicate together to drive correctly pump handle Heat/Cool signal.
  - a. Several BT-M6Z02-RF with global pump management
  - b. At least several BT-M6Z02-RF and one BT-HCM02-RF











#### 6.A.1 Standalone Installation Exemple of a "Standalone Installation"





----- RF Links to do



All those elements needs to be linked together, the RF link procedure can be done in this order:

Element 1 to link	Element 2 to link	Comments
<p><b>BT-M6Z02-RF</b></p>  <p>BT-M6Z02 RF</p>	<p><b>BT-S4Z / BT-S6Z</b></p>  <p>BT-S6Z02 RF</p>	No need to link them, just assemble S4Z or S6Z with BT-M6Z02-RF (both products OFF powered) and you can select the additional zones
<p><b>BT-M6Z02-RF</b></p>  <p>BT-M6Z02 RF</p> <p>Press OK for 5 seconds, first channel LED must blink. Choose the channels with &lt; and &gt; and select/deselect the zone with OK. When a zone is selected it turns Red. Note: To exit, press OK for 5 seconds.</p>	<p><b>BT-D03 RF / BT-D(P)02-RF / BT-A02-RF</b></p>  <p>Thermostats : Put product in RF Link mode (refer to correspondant instruction manual)</p>	If link is done, the leds of channels selected on the BT-M6Z02 RF must turn Green and the thermostats must exit the RF link mode.
<p><b>BT-M6Z02-RF</b></p>  <p>BT-M6Z02 RF</p> <p>Press &lt; for 5 seconds, all channel leds must blink Green. Product is waiting for link. Note: To exit, press &lt; for 5 seconds.</p>	<p><b>BT-WR02-RF</b></p>  <p>Put product in RF Link mode.</p>	In this configuration, BT-WR02-RF is used as on <b>remote pump device or boiler</b> : if there is a demand on the BT-M6Z02-RF, the device will command the output. When link is done BT-M6Z02-RF And BT-WR02-RF return to normal mode <b>REMARK:</b> instead of BT-WR02-RF, you can also use BT-FR02-RF and BT-PR02-RF
<p><b>BT-M6Z02-RF</b></p>  <p>BT-M6Z02 RF</p> <p>Press &lt; for 5 seconds, all channel leds must blink Green. Product is waiting for link. Note: To exit, press &lt; for 5 seconds.</p>	<p><b>BT-WR02-RF + BT-D02-RF/ BT-D03 RF</b></p>  <p><b>BT-WR02-RF must have been first linked with the thermostat.</b> Put <b>BT-WR02-RF</b> in RF Link mode.</p>	In this configuration, BT-WR02-RF is used as additional zone. When link is done BT-M6Z02-RF And BT-WR02-RF return to normal mode <b>REMARK 1:</b> instead of BT-WR02-RF, you can also use BT-FR02-RF and BT-PR02-RF <b>REMARK 2:</b> this configuration is only possible in Heating installation (no cooling)
<p><b>BT-M6Z02-RF</b></p>  <p>BT-M6Z02 RF</p> <p>Press &lt; for 5 seconds, all channel leds must blink Green. Product is waiting for link. Note: To exit, press &lt; for 5 seconds.</p>	<p><b>BT-HCM02-RF</b></p>  <p>BT-HCM02 RF</p> <p>Put product in RF Link mode.</p>	When link is done BT-M6Z02-RF And BT-HCM02-RF return to normal mode at the same time.

<p style="text-align: center;"><b>BT-M6Z02-RF</b></p>  <p style="text-align: center;">BT-M6Z02 RF</p> <p>Press &lt; for 5 seconds, all channel leds must blink Green. Product is waiting for link.</p> <p>Note: To exit, press &lt; for 5 seconds</p>	<p>Put the RF repeater in RF Link mode (press 3 s on the button)</p> 	<p>When link is done, BT-M6Z02-RF returns to normal mode and the led on the repeater becomes green fix.</p>
--	--	---

## 6.A.2 Centralyzed Installation


In this configuration, one BT-M6Z02-RF - called “Main” BT-M6Z02-RF - will centralize the information of the other BT-M6Z02-RF – called “Sub” BT-M6Z02-RF.



Its role is

- to propagate Heat and Cool signal to the system
- to handle the boiler / global pump for the whole system.

If there is a BT-HCM02-RF in the installation, it **MUST** be linked to “Main” BT-M6Z02-RF.

Exemple of a “Centralyzed Installation”




Element 1 to link	Element 2 to link	Comments
Do the RF Link procedure as in Standalone version then proceed with the RF link of all BT-M6Z02-RF		
<p style="text-align: center;"><b>« Main » BT-M6Z02-RF</b></p>  <p style="text-align: center;">BT-M6Z02 RF</p> <p>Press &lt; for 5 seconds, all channel leds must blink Green. Product is waiting for link.</p> <p>Note: To exit, press &lt; for 5 seconds.</p>	<p style="text-align: center;"><b>« Sub » BT-M6Z02-RF</b></p>  <p style="text-align: center;">BT-M6Z02 RF</p> <p>Press &gt; for 5 seconds, all channel leds must blink Red. Product is waiting for link.</p> <p>Note: To exit, press &gt; for 5 seconds.</p>	<p>When link is done, the two BT-M6Z02-RF return to normal mode.</p>







## 6.B. Installation with Touchscreen BT-CT02-RF





If there is a Touchscreen BT-CT02-RF in the installation, everything is centralized by the Touchscreen.

Exemple of an “Centralized Installation”



In this configuration, proceed with the RF link in this order:

Element 1 to link	Element 2 to link	Comments
<p><b>BT-M6Z02-RF</b></p>  <p>BT-M6Z02 RF</p> <p>Press OK for 5 seconds, first channel LED must blink. Choose the channels with &lt; and &gt; and select/deselect the zone with OK. When a zone is selected it turns Red. Note: To exit, press OK for 5 seconds.</p>	<p><b>BT-D03 RF / BT-D(P)02-RF / BT-A02-RF</b></p>  <p>Thermostats : Put product in RF Link mode (refer to correspondent instruction manual)</p>	<p>If link is done, the leds of channels selected on the BT-M6Z02 RF must turn Green and the thermostats must exit the link mode.</p>
<p><b>BT-M6Z02-RF</b></p>  <p>BT-M6Z02 RF</p> <p>Press &lt; for 5 seconds, all channel leds must blink Green. Product is waiting for link. Note: To exit, press &lt; for 5 seconds.</p>	<p><b>BT-HCM02-RF</b></p>  <p>BT-HCM02 RF</p> <p>Put product in RF Link mode.</p>	<p>When link is done BT-M6Z02-RF And BT-HCM02-RF return to normal mode.</p> <p><b>REMARK:</b> only one BT-HCM02-RF in the installation</p>

<p><b>BT-M6Z02-RF</b></p>  <p>BT-M6Z02 RF</p> <p>Press &gt; for 5 seconds, all channel leds must blink Red. Product is waiting for link. Note: To exit, press &gt; for 5 seconds.</p>	<p><b>BT-CT02-RF</b></p>  <p>BT-CT02 RF</p> <p>Link as a normal zone</p>	
<p><b>BT-CT02-RF</b></p>  <p>BT-CT02 RF</p> <p>Link « Circuit » device</p>	<p><b>BT-WR02-RF</b></p>  <p>BT-WR02 RF</p> <p>Put product in RF Link mode.</p>	<p>In this configuration, BT-WR-WR02-RF is used as <b>hydraulic circuit device</b>: Refer to the instruction manual of BT-CT02-RF for further explanation.</p>

**Be careful! Link BT-M6Z02-RF to BT-CT02-RF, once ALL thermostats to BT-M6Z02-RF have been linked.**

## 7 SPECIAL FUNCTIONS

### Humidity management

This feature is available on thermostats that have Humidity sensor (BT-D02RF RH and BT-DP02RF RH).

Please refer to thermostat instruction manual to correctly set the parameters.

- If there is a humidity default (dew point or humidity threshold), then cooling on the zone is stopped (stops flow in the zone).
- If in the installation there is a BT-HCM02-RF and dehumidifier is active then if there is humidity default, dehumidifier is active

### Pump Delay (not configurable)

To avoid pump damage and noise in hydraulic circuit (Water flow in the pipe) the start-up of the pump will be delayed for 1 minute after a heating demand from the zone thermostats. This delay should allow the actuator to be completely opened before the activation of the pump.

### Valve exercise (not configurable)

To prevent the valves from seizing, each valve is automatically activated 2 minutes per week.

### Factory settings function:

Use this function to erase all configurations, RF links and restore factory settings.

In 'Run mode', press in the same time during 5 seconds the 2 keys (◀) and (▶).

Then the product has been resetted.